
LS6301 Junction Box Adapter



Dimensions




READ ALL SAFETY INSTRUCTIONS FIRST

- > Follow instructions carefully, failure to do so will void warranty.
- > Luminaire is factory sealed, opening luminaire will void warranty

LUMASCAPE ASIA PACIFIC Brisbane Technology Park, 18 Brandl Street, Eight Mile Plains, QLD 4113, Australia Phone +61 7 3854 5000 | Fax +61 7 3854 5001 | Email: sales@lumascape.com.au | www.lumacape.com



North American Market Installation



Secure all connections, luminaires and junction box covers


Use weatherproof junction boxes and seal all possible water entry points and covers using RTV silicone.



Sealing compound and Junction box supplied by others.


Cable Seal

Use appropriate seal silicone gland according to luminaire cable, four options available



Earth Wire

Ensure that wiring is earthed within junction box




INSTALLATION INSTRUCTIONS

LS6301 Junction Box Adapter



International Market Installation





Make connections and conceal cabling within wall cavity

Secure all connections and luminaires


Seal all possible water entry points and covers using RTV silicone.




Sealing compound supplied by others.

Cable Seal

Use appropriate seal silicone gland according to luminaire cable, four options available







LUMASCAPE ASIA PACIFIC Brisbane Technology Park, 18 Brandl Street, Eight Mile Plains, QLD 4113, Australia Phone +61 7 3854 5000 | Fax +61 7 3854 5001 | Email: sales@lumascape.com.au | www.lumacape.com